



MERIDA BIG TRAIL CABLE GUIDE PROCESS

Step 1 - remove T10 screw



Step 2 - Push plate into downtube



Step 3 - feed cable plate out through access hole



Step 4 - loosen two plate bolts



Step 5 - adjust cable position
Step 6 - tighten two plate bolts



Step 7 - install plate into frame
Step 8 - locate front of plate in hole
Step 9 - pull on cable to locate plate (should hear an audible click)
Step 10 - install T10 screw

